


For the latest Retrotec documentation, visit us at: <http://www.retrotec.com/info/>

## 1 Secure the door in the open position

- 1.1 Select a doorway, between 29.5" to 41.5" in width, and 51.5" to 95" in height.
- 1.2 The door must be held open securely during testing.




## 2 Unpack the Aluminum Frame

- 2.1 Remove the frame pieces from the case.
- 2.2 A complete set includes one cloth panel, two long and two short frame parts, a crossbar, and a fan strap (attached to crossbar).
- 2.3 Optional crossbar/frame extenders or cloth panels can be ordered if required.




## 3 Lay out the pieces

- 3.1 Arrange the aluminum frame sections on the floor.
- 3.2 Match the corners according to the numbers stamped on each section.
- 3.3 Ensure all cam levers are "unlocked" (cam handles should be parallel to frame).



## 4 Assemble the corners

- 4.1 Press in the spring-loaded button and slide the sections together until the spring-loaded button locks the pieces into position.
- 4.2 Loosen all four black knobs to allow the frame sections to be resized.




**Tip:** If any of the pieces are loose, use the included Allen Key to tighten the screws.



## 5 Size the frame to the doorway

- 5.1 Position the frame in the doorway, and extend the frame until each side is in contact with the door frame.
- 5.2 Tighten the black knobs but leave the cam levers in the "unlocked" position.
- 5.3 Insert and extend the crossbar into the slots at position '5'.




**Tip:** Fit the frame so that it is tight enough to remain standing in the doorway, but can be removed with a slight pull.


## 6 Attach the cloth panel

- 6.1 Unfold the cloth panel and drape it over the frame.
- 6.2 Attach the bottom Velcro tabs first, evenly along the bottom of the frame.

**Tip:** Setting the frame on its side, or flat on the floor, will make it easier to attach the cloth panel. Make sure the black knobs and cams are still accessible once the panel is attached.



- 6.3 Fold the cloth panel over the top, right and left of the frame.
- 6.4 Connect the vertical and horizontal Velcro strips to secure the cloth.
- 6.5 Make sure that the fan hole is not stretched, or the fan will not have a proper seal when mounted in the panel cloth.



## 7 Replace the panel


- 7.1 Place the assembled panel in the doorway.
- 7.2 If the frame does not fit snugly, loosen the black knobs, and extend the frame tight against the door frame.
- 7.3 Holding the frame taut, tighten all black knobs as shown in the picture.

**Tip:** Step on bottom of frame while securing the cams to ensure a tight fit.



## 8 Engage cam levers

- 8.1 Engage the cam levers on the frame at the top, left, right, and bottom and center locations.
- 8.2 Tug on the frame to ensure a tight fit.



## 9 Tighten the fan hole

- 9.1 If the fan is not able to fit securely in the fan hole, tighten the fan hole elastic.
- 9.2 The elastic can be found at the top of the fan hole. Pull the elastic to tighten.



## 10 Double fan cloth (optional)

Mount two fans with the optional two-fan cloth plus a second crossbar..



## 11 Frame extender kit (optional)

The aluminum frame can be extended in both width and height with the optional Frame Extender Kit.

Frame Extender Kit includes:  
- 2 vertical extenders


- 2 horizontal extenders

- 1 #5, and - 1 #6 crossbar extender

- 1 #6 Upper crossbar

- 1 allen key


- 1 extra-tall, extra-wide cloth door panel



## 12 Extend the height - Step 1 (optional)

12.1 Remove the corner pieces from the corners of the aluminum frame.

12.2 Attach the corner pieces to the vertical extenders




## 13 Extend the height - Step 2 (optional)

13.1 Attach the vertical extenders to the aluminum frame.

13.2 Attach the #6 crossbar to the frame where it's labeled '6'.


13.3 Attach the #5 crossbar to the frame as usual.



## 14 Extend the width (optional)

Attach the connector pieces to the horizontal sections, tightening the black knob in the connector hole to secure the frame.

14.1 Add horizontal extenders  
14.2 Add crossbar extender  
14.3 Add the additional crossbar extender to the #6 crossbar if required.



## 15 Extend the height and width (optional)

15.1 Use both the height and width extender kits to maximize the size of the frame.

15.2 Attach the extra-tall, extra-wide cloth door panel